





WARNING: The air suspension system is under pressure (up to 10 bar, or 150 lbf/in). Verify pressure has been relieved and disconnect power to the air suspension system prior to disassembly. Do not allow dirt or grease to enter the system. Always wear standard hand, ear, and eye protection when servicing the air suspension system.



GENERAL INFORMATION:

- Not to be stored below 5°F (-15°C) or above 122°F (50°C).
- Avoid damage to air lines and cables.
- Removal and installation is only to be performed by fully qualified personnel.
- Use car manufacturer's diagnostic software.

CAUTION: Damage to the vehicle and air suspension system can be incurred if work is carried out in a manner other than specified in the instructions or in a different sequence.



To avoid the possibility of short circuits while working with electric components consult your owner's manual on how to disconnect your battery.



Consult your vehicle owner's manual, service manual, or car dealer for the correct jacking points on your vehicle and for additional care, safety and maintenance instructions. Under no circumstances should any work be completed underneath the vehicle if it is not adequately supported, as serious injuries and death can occur.



Once the vehicle has been raised from the ground, put vehicle in neutral, and then back into park to release the tension on the drivetrain.

AIR STRUT REMOVAL

- RAISE VEHICLE.
- 2. REMOVE REAR WHEEL.
- 3. REMOVE THE LUGGAGE COMPARTMENT SIDE TRIM TO EXPOSE THE TOP SIDES OF THE AIR STRUT. (FIGURE A)



FIGURE A



DISCONNECT THE AIR LINE FROM THE CHECK VALVE. (FIGURE B) 4.



FIGURE B

REMOVE THE AIR LINE FITTING FROM THE AIR HOSE AND DISCARD. (FIGURE B) 5.




#1

3



Prior to inserting the existing air line into the new air fitting you will need to remove the old original equipment air line fitting.



OE AIR LINE FITTING

SLIDE THE THREADED PORTION UP THE LINE AND SPREAD THE COLLET OPEN TO REMOVE

SLIDE THE AIR FITTING OFF OF THE AIR LINE

AIR LINE IS READY FOR INSTALLATION

NOTE: SCRATCHES AND/OR

AIR LINE CAN RESULT IN POSSIBLE

DEEP CUTS IN THE

SSAS02891N REV₁ 08/01/2016



5. DISCONNECTTHE ELECTRICAL CONNECTOR FROM THE TOP OF THE AIR STRUT (PUSH ON THE SIDES OF THE CONNECTOR TO RELEASE. (FIGURE C)




FIGURE C

6. REMOVE THE FOUR (4) AIR STRUT MOUNTING NUTS. (FIGURE D)




FIGURE D



7. DETACH THE REAR TIE ROD. (FIGURE E)



FIGURE E

8. REMOVETHE LOWER AIR STRUT MOUNTING BOLT. (FIGURE F)



FIGURE F



9. REMOVE AIR STRUT. (FIGURE G)



FIGURE G

10. REMOVAL COMPLETE.

AIR STRUT INSTALLATION



Tighten all nuts and bolts to manufacturer's specifications during the installation process.



Do not remove the air fitting from the air strut. Doing so may cause damage and/or void warranty. Remove the white shipping pin from the new air fitting and insert the air line until fully seated.

1. INSTALLATION IS IN REVERSE ORDER OF AIR STRUT REMOVAL. REUSING FACTORY HARDWARE WHERE APPLICABLE.