

LAND ROVER

LAND ROVER FREELANDER I (L314)

| Modello | Anno di Produzione | Cil | KW | CV | Cilindri | Alimentazione | Codice Motore |
|---------------------|-------------------------|----------|--------|--------|------------|---------------|---------------|
| FREELANDER I (L314) | 1998-02-01 - 2000-11-01 | 1796 ccm | 88 KW | 120 CV | 4 Cilindri | Benzina | 18 K4F |
| FREELANDER I (L314) | 1998-02-01 - 2000-11-01 | 1994 ccm | 72 KW | 98 CV | 4 Cilindri | Diesel | 20 T2N |
| FREELANDER I (L314) | 1998-04-01 - 2006-10-01 | 1796 ccm | 86 KW | 117 CV | 4 Cilindri | Benzina | 18 K4F |
| FREELANDER I (L314) | 2000-11-01 - 2006-10-01 | 2497 ccm | 130 KW | 177 CV | 6 Cilindri | Benzina | 25 K4F |
| FREELANDER I (L314) | 2000-11-01 - 2006-10-01 | 1951 ccm | 82 KW | 112 CV | 4 Cilindri | Diesel | 204D3 |
| FREELANDER I (L314) | 2000-11-01 - 2006-10-01 | 1951 ccm | 82 KW | 112 CV | 4 Cilindri | Diesel | M 47 |
| FREELANDER I (L314) | 2001-03-01 - 2006-10-01 | 1951 ccm | 80 KW | 109 CV | 4 Cilindri | Diesel | 204D3 |