

TOYOTA

TOYOTA LAND CRUISER 80 (_J8_)

Modello	Anno di Produzione	Cil	KW	CV	Cilindri	Alimentazione	Codice Motore
LAND CRUISER 80 (_J8_)	1990-01-01 - 1991-09-01	2982 ccm	92 KW	125 CV	4 Cilindri	Diesel	1KZ-T
LAND CRUISER 80 (_J8_)	1990-01-01 - 1992-08-01	3470 ccm	85 KW	116 CV	5 Cilindri	Diesel	1PZ
LAND CRUISER 80 (_J8_)	1990-01-01 - 1992-10-01	3956 ccm	115 KW	156 CV	6 Cilindri	Benzina	3F-E
LAND CRUISER 80 (_J8_)	1990-01-01 - 1993-05-01	2367 ccm	77 KW	105 CV	4 Cilindri	Benzina	22R
LAND CRUISER 80 (_J8_)	1990-01-01 - 1997-12-01	4164 ccm	123 KW	167 CV	6 Cilindri	Diesel	1HD-T
LAND CRUISER 80 (_J8_)	1990-01-01 - 1997-12-01	4164 ccm	99 KW	135 CV	6 Cilindri	Diesel	1H-Z
LAND CRUISER 80 (_J8_)	1992-08-01 - 1997-12-01	4477 ccm	151 KW	205 CV	6 Cilindri	Benzina	1FZ-FE
LAND CRUISER 80 (_J8_)	1992-08-01 - 1997-12-01	4477 ccm	158 KW	215 CV	6 Cilindri	Benzina	1FZ-FE
LAND CRUISER 80 (_J8_)	1992-08-01 - 1998-01-01	4477 ccm	215 KW	292 CV	6 Cilindri	Benzina	1FZ-FE
LAND CRUISER 80 (_J8_)	1992-10-01 - 1997-12-01	4164 ccm	118 KW	160 CV	6 Cilindri	Diesel	1HD-T
LAND CRUISER 80 (_J8_)	1992-11-01 - 1999-11-01	4477 ccm	165 KW	224 CV	6 Cilindri	Benzina	1FZ-FE
LAND CRUISER 80 (_J8_)	1995-01-01 - 1997-12-01	4164 ccm	125 KW	170 CV	6 Cilindri	Diesel	1HD-FT