

CITROËN

CITROËN XANTIA (X1_, X2_)

Modello	Anno di Produzione	Cil	KW	CV	Cilindri	Alimentazione	Codice Motore
XANTIA (X1_, X2_)	1993-03-01 - 1995-05-01	1998 ccm	95 KW	129 CV	4 Cilindri	Benzina	RFX XU10J2C/Z L3
XANTIA (X1_, X2_)	1993-03-01 - 1998-01-01	1761 ccm	74 KW	101 CV	4 Cilindri	Benzina	LFZ (XU7JP)
XANTIA (X1_, X2_)	1993-03-01 - 1998-01-01	1998 ccm	112 KW	152 CV	4 Cilindri	Benzina	RFY (XU10J4/Z)
XANTIA (X1_, X2_)	1993-03-01 - 2001-03-01	1580 ccm	65 KW	88 CV	4 Cilindri	Benzina	BFZ (XU5JP)
XANTIA (X1_, X2_)	1993-03-01 - 2003-04-01	1998 ccm	89 KW	121 CV	4 Cilindri	Benzina	RFX (XU10J2C)
XANTIA (X1_, X2_)	1993-05-01 - 2003-04-01	1905 ccm	66 KW	90 CV	4 Cilindri	Diesel	DHX (XUD9TF/BTF)
XANTIA (X1_, X2_)	1993-05-01 - 2003-04-01	1905 ccm	66 KW	90 CV	4 Cilindri	Diesel	DHY (XUD9TE/Y)
XANTIA (X1_, X2_)	1994-06-01 - 1998-01-01	1998 ccm	110 KW	150 CV	4 Cilindri	Benzina	RFT (XU10J4/Z)
XANTIA (X1_, X2_)	1994-06-01 - 1998-01-01	1905 ccm	50 KW	68 CV	4 Cilindri	Diesel	DJZ (XUD9A)
XANTIA (X1_, X2_)	1994-06-01 - 1998-01-01	1905 ccm	51 KW	69 CV	4 Cilindri	Diesel	D9B (XUD9A/L)
XANTIA (X1_, X2_)	1995-06-01 - 1999-02-01	2088 ccm	80 KW	109 CV	4 Cilindri	Diesel	P8C (XUD11BTE)
XANTIA (X1_, X2_)	1995-06-01 - 2001-12-01	1761 ccm	81 KW	110 CV	4 Cilindri	Benzina	LFY (XU7JP4)
XANTIA (X1_, X2_)	1995-06-01 - 2003-04-01	1998 ccm	108 KW	147 CV	4 Cilindri	Benzina	RGX (XU10J2TE)
XANTIA (X1_, X2_)	1995-06-01 - 2003-04-01	1998 ccm	97 KW	132 CV	4 Cilindri	Benzina	RFV (XU10J4R)
XANTIA (X1_, X2_)	1996-02-01 - 2003-04-01	1905 ccm	55 KW	75 CV	4 Cilindri	Diesel	DHW (XUD9SD)
XANTIA (X1_, X2_)	1997-01-01 - 2003-04-01	2946 ccm	140 KW	190 CV	6 Cilindri	Benzina	XFZ (ES9J4)
XANTIA (X1_, X2_)	1997-04-01 - 2003-04-01	1761 ccm	66 KW	90 CV	4 Cilindri	Benzina	LFX (XU7JB)
XANTIA (X1_, X2_)	1998-01-01 - 2003-04-01	2946 ccm	142 KW	194 CV	6 Cilindri	Benzina	XFZ (ES9J4)
XANTIA (X1_, X2_)	1998-06-01 - 2000-11-01	1998 ccm	99 KW	135 CV	4 Cilindri	Benzina	RFV (XU10J4R)
XANTIA (X1_, X2_)	1999-02-01 - 2003-04-01	1997 ccm	80 KW	109 CV	4 Cilindri	Diesel	RHZ (DW10ATED)
XANTIA (X1_, X2_)	1999-03-01 - 2003-04-01	1997 ccm	66 KW	90 CV	4 Cilindri	Diesel	RHY (DW10TD)

CITROËN XANTIA Break (X1_, X2_)

Modello	Anno di Produzione	Cil	KW	CV	Cilindri	Alimentazione	Codice Motore
XANTIA Break (X1_, X2_)	1995-06-01 - 1998-01-01	1761 ccm	74 KW	101 CV	4 Cilindri	Benzina	LFZ (XU7JP)
XANTIA Break (X1_, X2_)	1995-06-01 - 2003-04-01	1905 ccm	66 KW	90 CV	4 Cilindri	Diesel	D8B (XUD9TF)
XANTIA Break (X1_, X2_)	1995-06-01 - 2003-04-01	1905 ccm	66 KW	90 CV	4 Cilindri	Diesel	DHY (XUD9TE/Y)
XANTIA Break (X1_, X2_)	1995-06-01 - 2003-04-01	1905 ccm	66 KW	90 CV	4 Cilindri	Diesel	DHX (XUD9TF/BTF)
XANTIA Break (X1_, X2_)	1995-06-01 - 2003-04-01	1998 ccm	97 KW	132 CV	4 Cilindri	Benzina	RFV (XU10J4R)
XANTIA Break (X1_, X2_)	1995-06-01 - 2003-04-01	1761 ccm	81 KW	110 CV	4 Cilindri	Benzina	LFY (XU7JP4)
XANTIA Break (X1_, X2_)	1995-06-01 - 2003-04-01	1998 ccm	89 KW	121 CV	4 Cilindri	Benzina	RFX (XU10J2C)
XANTIA Break (X1_, X2_)	1995-06-01 - 2003-04-01	1998 ccm	108 KW	147 CV	4 Cilindri	Benzina	RGX (XU10J2TE)
XANTIA Break (X1_, X2_)	1996-06-01 - 1999-02-01	2088 ccm	80 KW	109 CV	4 Cilindri	Diesel	P8C (XUD11BTE)
XANTIA Break (X1_, X2_)	1997-04-01 - 2003-04-01	1905 ccm	55 KW	75 CV	4 Cilindri	Diesel	DHW (XUD9SD)
XANTIA Break (X1_, X2_)	1997-04-01 - 2003-04-01	1761 ccm	66 KW	90 CV	4 Cilindri	Benzina	LFX (XU7JB)
XANTIA Break (X1_, X2_)	1998-01-01 - 2003-04-01	2946 ccm	140 KW	190 CV	6 Cilindri	Benzina	XFZ (ES9J4)
XANTIA Break (X1_, X2_)	1999-02-01 - 2003-04-01	1997 ccm	80 KW	109 CV	4 Cilindri	Diesel	RHZ (DW10ATED)
XANTIA Break (X1_, X2_)	1999-03-01 - 2003-04-01	1997 ccm	66 KW	90 CV	4 Cilindri	Diesel	RHY (DW10TD)