

# TOYOTA

## TOYOTA LAND CRUISER 100 (\_J1\_)

Modello	Anno di Produzione	Cil	KW	CV	Cilindri	Alimentazione	Codice Motore
LAND CRUISER 100 (_J1_)	1998-01-01 - 2002-07-01	4164 ccm	151 KW	205 CV	6 Cilindri	Diesel	1HD-FTE
LAND CRUISER 100 (_J1_)	1998-01-01 - 2002-07-01	4164 ccm	123 KW	167 CV	6 Cilindri	Diesel	1HD-T
LAND CRUISER 100 (_J1_)	1998-01-01 - 2007-07-01	4477 ccm	158 KW	215 CV	6 Cilindri	Benzina	1FZ-FE
LAND CRUISER 100 (_J1_)	1998-01-01 - 2007-08-01	4664 ccm	173 KW	235 CV	8 Cilindri	Benzina	2UZ-FE
LAND CRUISER 100 (_J1_)	1998-01-01 - 2007-08-01	4164 ccm	150 KW	204 CV	6 Cilindri	Diesel	1HD-FTE
LAND CRUISER 100 (_J1_)	1998-01-01 - 2007-08-01	4664 ccm	170 KW	233 CV	8 Cilindri	Benzina	2UZ-FE
LAND CRUISER 100 (_J1_)	1998-01-01 - 2007-08-01	4164 ccm	153 KW	208 CV	6 Cilindri	Diesel	1HD-FTE
LAND CRUISER 100 (_J1_)	1998-01-01 - 2008-07-01	4477 ccm	173 KW	235 CV	6 Cilindri	Benzina	1FZ-FE
LAND CRUISER 100 (_J1_)	1998-03-01 - 2007-08-01	4164 ccm	96 KW	131 CV	6 Cilindri	Diesel	1H-Z
LAND CRUISER 100 (_J1_)	1998-03-01 - 2008-07-01	4477 ccm	165 KW	224 CV	6 Cilindri	Benzina	1FZ-FE
LAND CRUISER 100 (_J1_)	2002-02-01 - 2007-08-01	4664 ccm	175 KW	238 CV	8 Cilindri	Benzina	2UZ-FE