



SSA02791N
DI.PA. SPORT LEFT REAR AIR SPRING
MERCEDES-BENZ CLS-CLASS
MERCEDES-BENZ E-CLASS
ALL W/AIRMATIC (INCL. AMG)
CHASSIS: W212

Congratulations on your purchase of an air suspension product. We are proud to offer a high quality product at the industry's most competitive pricing. Thank you for your confidence in us and our product.

Proper installation is essential to experience and appreciate the benefits of this system. Please take a moment to review these installation instructions before you begin to install these components on your vehicle. The removal and installation of air suspension products should only be performed by a fully qualified, ASE Certified, professional.

It is equally important to be aware of all necessary safety measures while installing your new Air Suspension System. This includes proper lifting and immobilizing of the vehicle and isolation of any stored energy to prevent personal injury or property damage.



WARNING: *The air suspension system is under pressure (up to 10 bar, or 150 lbf/in). Verify pressure has been relieved and disconnect power to the air suspension system prior to disassembly. Do not allow dirt or grease to enter the system. Always wear standard hand, ear, and eye protection when servicing the air suspension system.*



SSA02791N
DI.PA. SPORT LEFT REAR AIR SPRING
MERCEDES-BENZ CLS-CLASS
MERCEDES-BENZ E-CLASS
ALL W/AIRMATIC (INCL. AMG)
CHASSIS: W212

GENERAL INFORMATION:

- Not to be stored below 5°F (-15°C) or above 122°F (50°C).
- Avoid damage to air lines and cables.
- Removal and installation is only to be performed by fully qualified personnel.
- Use car manufacturer's diagnostic software.

CAUTION: *Damage to the vehicle and air suspension system can be incurred if work is carried out in a manner other than specified in the instructions or in a different sequence.*



To avoid the possibility of short circuits while working with electric components consult your owner's manual on how to disconnect your battery.



Consult your vehicle owner's manual, service manual, or car dealer for the correct jacking points on your vehicle and for additional care, safety and maintenance instructions. Under no circumstances should any work be completed underneath the vehicle if it is not adequately supported, as serious injuries and death can occur.

AIR SPRING REMOVAL

1. Raise vehicle and remove rear wheel to expose the rear air spring. (FIGURE 10-1)



FIGURE 10-1



SSA02791N
DI.PA. SPORT LEFT REAR AIR SPRING
MERCEDES-BENZ CLS-CLASS
MERCEDES-BENZ E-CLASS
ALL W/AIRMATIC (INCL. AMG)
CHASSIS: W212

2. Locate and remove the air line fitting to deflate the rear air spring. (FIGURES 10-2, 10-3)



FIGURE 10-2



FIGURE 10-3

3. Remove the air line fitting from the air hose and discard. (FIGURES 10-4, 10-5)



FIGURE 10-4



FIGURE 10-5

4. Carefully pull down the top of the air spring to detach it from its upper mount retaining clip. (FIGURE 10-6)



FIGURE 10-6



SSA02791N
DI.PA. SPORT LEFT REAR AIR SPRING
MERCEDES-BENZ CLS-CLASS
MERCEDES-BENZ E-CLASS
ALL W/AIRMATIC (INCL. AMG)
CHASSIS: W212

5. Pull up on the bottom of the air spring to separate it from the lower spring seat. (FIGURE 10-7)



FIGURE 10-7

6. Remove the rear air spring from the vehicle. (FIGURE 10-8)



FIGURE 10-8

7. Removal complete.

AIR SPRING INSTALLATION



Tighten all nuts and bolts to manufacturer's specifications during the installation process.



Refer to the "Facing Wheel" label on the new part for the correct orientation when fitting onto the vehicle.

1. Installation is in reverse order of air spring removal.